

1. Remove Telescoping flagpole from the ground sleeve
2. Place clamp over top of the installed ground sleeve (clamp must make full contact with sleeve)
3. Re-install flagpole fully in the ground sleeve
4. Use correct size wrench or socket to tighten down locknut on clamp (do not over-tighten)

